Gable End Wind Bracing Details - Stiffback w/ Diagonal Bracing

Apply single or double stiffback as per Engineer's sealed truss design referencing this detail.


Refer to Engineer's sealed truss design for additional information not provided on this detail.


The required locations for lateral restraint or bracing depicted on this detail are for the permanent lateral transfer and support to transfer load and reduce buckling lengths. Details shall be specified by the Building Designer or other Registered Design Professional. This Detail does not depict or specify installation/erection bracing, wind bracing, portal bracing or similar building stability bracing which are parts of the overall building design to be specified, designed, and detailed by the Building Designer.


Refer to Building Designer for conditions not addressed by this detail.

Gable Lateral Bracing Components

- (A) Stiffback, Provide connection to each intersecting stud and chord,
- (B) L-reinforcement. Provide connection to narrow edge of stiffback.
- (C) Diagonal brace. Provide connection to gable stud at bottom end and to blocking at top end.
- (D) Blocking, cut to fit tight between trusses. Attach blocking to trusses at each end and to roof sheathing.







VARNINGI READ AND FOLLOW ALL NOTES ON THIS DRAWING ***IMPORTANT*** FURNISH THIS DRAWING TO ALL CONTRACTORS INCLUDING THE INSTALLERS.

Trusses require extreme care in fabricating, handling, shipping, installing and inracing. Refer to and follow the latest edition of BCSI (Building Component Safety Information, br PI and SBCA) for safety practices prior to performing these functions. Installers shall provide temporary bracing per BCSI. Unless noted otherwise, top chord shall have properly attached structural sheathing and bottom chord shall have a properly attached rigid celling. Locations shown for permanent lateral restraint of webs shall have bracing installed per BCSI sections B3, B7 or B10, as applicable. Apply plates to each face of truss and position as shown above and on the Joint Details, unless noted otherwise.

Refer to drawings 160A-Z for standard plate positions.

Alpine, a division of ITV Building Components Group Inc. shall not be responsible for any deviation from this drawing, any failure to build the truss in conformance with ANSI/TPI 1, or for handling, shipping, installation & bracing of trusses.

A seal on this drawing or cover page listing this drawing, indicates acceptance of professional engineering responsibility solely for the design shown. The suitability and use of this drawing for any structure is the responsibility of the Building Designer per ANSI/TPI 1 Sec.2.

For more information see this job's general notes page and these web sites: ALPINE: www.alpineitw.com; TPI: www.tpinst.org; SBCA: www.sbcacomponents.com; ICC: www.iccsafe.org

GE STIFFBACK DATE 09/27/2023 DRWG GBLDIAG220923

MAX. TOT. LD.

MAX. SPACING

155 Harlem Ave North Building, 4th Floor Glenview, IL 60025